Product Specification Report

V 1.0



BATTERY CARE NEW is a detergent for cleaning and protecting battery terminals. It contains a special marker which, when it changes colour, indicates the presence of liquid leaks.

BATTERY CARE NEW

Detergent-Rust remover-Sealant for batteries

FEATURES:

Colour change indicator	Changes colour from yellow to red in the presence of battery acid. Indicates whether, and where, acid is found.
Protective effect	Leaves a slight protective layer on contacts and on cables that protects them from corrosion.
Easy to apply	It is sprayed on as a foam that adheres to the surfaces on which it is applied, ensuring maximum efficiency.

SPECIFICATIONS:

Chemical and physical properties	Values
Form	Spray can
Colour	White
Odour	Characteristic
pH (as is)	11.4 ± 0.5
Specific weight	1.07 g/cm ³
COV	9%

ACTIVE INGREDIENTS:

- Detergents
- Alkaline
- Neutralizing agents
- Penetrating agents
- Colour markers

COMPATIBILITY:

It does not damage the materials of the battery, cables, terminals, rubber, paint, plastic. May stain some paints, fabrics or finishes: always do a compatibility test prior to use.

INSTRUCTIONS:

Shake the container before use. Make sure that the battery cells are hermetically sealed. Spray the product covering the entire surface of the battery. Leave it on for 5-7 minutes. When applied, the product is yellow, it turns red in the presence of acid. In this case, continue to apply until the solution turns vellow. Rinse to remove corrosion and dirt from cracks, poles, cables and casing, wipe with a cloth or use compressed air. Re-apply a light coating of BATTERY CARE NEW over the entire battery ensuring it penetrates into the clamps, cable terminals and bolts. Repeat periodically to maintain a protective layer on all the treated structures. When new or used batteries are stored, isolate them from the floor and cover with BATTERY CARE NEW.

SAFETY PRECAUTIONS:

For further information, please refer to the safety data sheet.

All the information in this document is based on our practical experience and/or laboratory tests. Because of the wide spectrum of conditions for the use and unpredictable human factors, you should always test our products before final use. This technical data sheet may already have been revised pursuant to current legislation, the availability of individual ingredients or newly acquired information. We are able to send, upon request, the latest applicable version, which is at the same time the most up-to-date version.