



# Product Specification Report

Rev. 1.0

**A special product in tablet form which prevents clogging of drains, effective against the accumulation of dirt**

## ZEP TABS EVO

Tablets for treatment of drain and drip trays of AC systems

### FEATURES:

<b>Triple action</b>	Contains specialized disinfectants, corrosion inhibitors and detergents for the full treatment of the system: prevents bacteria, cleans and controls corrosion
<b>Smart blister</b>	Blister in two parts: the blister in two parts ensures, on the one hand, the immediate release of the active ingredients (smaller part) and, secondly, a constant long-term dosage (larger part with sponge).
<b>New waxy formula</b>	The new waxy tablet provides a more gradual release of the active ingredients over a certain period of time, increases in particular the disinfecting power for the whole season.
<b>Biological control</b>	Effectively prevents the growth of bacteria and algae that cause a variety of deposits and blockages in the system. Tested on: <i>Legionella pneumophila</i> , <i>Staphylococcus aureus</i> and <i>Pseudomonas aeruginosa</i> according to UNI EN 1040: 2005.
<b>Protects</b>	Protects walls, ceilings and floors against condensate overflow
<b>Safe</b>	Does not harm plastics or other parts of the air conditioning system
<b>Prevents bad odours</b>	Combats the smell of stale water

### APPLICATIONS:

Ideal for use in hotels, offices, restaurants, hospitals, apartment buildings, refrigerated rooms of stores, vending machines, industrial air-conditioning units, etc.

### INSTRUCTIONS FOR USE:

Take the tablet from the plastic bag. Separate the two blisters with the help of the pre-cut grid. Place the blister on a flat surface and press with your thumb firmly on the lower part of the blister to activate the product. Place the blister in the drip tray with the sponge side down so that the condensate can wet the tablets and can gradually release the active ingredients. A single blister treats an individual airco for an entire season (5 to 6 months).

### PRECAUTIONS FOR USE:

Consult the MSDS for more information.

### SPECIFICATIONS:

Form .....Waxy solid  
Colour .....Yellow  
Solubility in water .....Soluble  
Packaging.....Tablet in transparent blister  
Tablet size (cm) .....17,6 (L)x 4,5 (W) x 1,7 (H)

All information in this document is based on our practical experience and/or laboratory tests. Due to the multiplicity of conditions for usage and variable human factors, we recommend that you always test our products for suitability prior to use. At any time, this version of the product specification report may have been revised based on legislation, availability of the individual ingredients or newly acquired information. The current approved version is available upon request.



**Zep Italia s.r.l.**  
T • 800 016 918  
Numero Verde Tecnico  
800-579185  
a tecnico@zepeurope.com  
www.zep.it



**Zep UK Ltd.**  
T • 0151 422 1000  
F • 0151 422 1011  
info@zep.co.uk  
www.zep.co.uk



**Zep Industries BV**  
T • 02 347 01 17  
F • 02 347 13 95  
sales@zep.be  
www.zepindustries.be



**Zep Industries BV**  
T • 0164 250100  
F • 0164 266710  
info@zepbenelux.com  
www.zepindustries.nl



**Zep Industries BV**  
T • 0521 174158  
F • 0521 5217114  
sales@zepbenelux.com  
www.zepindustries.de